

Installation Materials – Make the right connections. Straight talk builds true business.



<p>Surface Mounted Junction Boxes</p>	<table border="0"> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>Junction box IP20 AP6 IP20 AP6.2 Grey, 60x60 mm, incl. connector</td> <td>Junction box IP20 AP12 IP20 AP12.1 without conn.</td> <td>Surface-mounted junction box IP 65 AP75 IP65</td> <td>Junction box IP 55 AP9 white AP9M black AP9/G grey</td> <td>Junction box IP55 AP10 white AP10/G grey</td> <td>Junction box IP44 AP7 IP44</td> <td>Junction box with connection cover IP44 AP7.1 IP44</td> </tr> </table>								Junction box IP20 AP6 IP20 AP6.2 Grey, 60x60 mm, incl. connector	Junction box IP20 AP12 IP20 AP12.1 without conn.	Surface-mounted junction box IP 65 AP75 IP65	Junction box IP 55 AP9 white AP9M black AP9/G grey	Junction box IP55 AP10 white AP10/G grey	Junction box IP44 AP7 IP44	Junction box with connection cover IP44 AP7.1 IP44	<p>Accessories for Surface Mounted Junction Boxes</p> <table border="0"> <tr> <td></td> <td></td> <td></td> </tr> <tr> <td>Accessories for AP75 AS12.3 Strain relief</td> <td>Strain-relief and connector AS9</td> <td>Strain-reliefs AS9.1 for 1 cable AS9.3 for 3 cables</td> </tr> </table>				Accessories for AP75 AS12.3 Strain relief	Strain-relief and connector AS9	Strain-reliefs AS9.1 for 1 cable AS9.3 for 3 cables																		
Junction box IP20 AP6 IP20 AP6.2 Grey, 60x60 mm, incl. connector	Junction box IP20 AP12 IP20 AP12.1 without conn.	Surface-mounted junction box IP 65 AP75 IP65	Junction box IP 55 AP9 white AP9M black AP9/G grey	Junction box IP55 AP10 white AP10/G grey	Junction box IP44 AP7 IP44	Junction box with connection cover IP44 AP7.1 IP44																																		
Accessories for AP75 AS12.3 Strain relief	Strain-relief and connector AS9	Strain-reliefs AS9.1 for 1 cable AS9.3 for 3 cables																																						
<p>Piping Materials</p>	<table border="0"> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>Conduit extensions AJ16 Ø 16 mm AJ20 Ø 20 mm AJ25 Ø 25 mm AJ32 Ø 32 mm AJ40 Ø 40 mm AJ50 Ø 50 mm</td> <td>Bushing flange AS20 For conduit extension Ø 20 mm</td> <td>Conduit adaptor AJ16.20 Ø 16 mm / 20 mm</td> <td>The Flexible conduit extension AJP20 Ø 20 mm</td> <td>Bushing insulators AJ9.16 Ø 16 mm AJ10.20 Ø 20 mm AJ10.25 Ø 25 mm</td> <td>Bushing insulators AJ13 Ø 32 mm, 90° AJ14 Ø 40 mm, 90° AJ15 Ø 50 mm, 90° AJ15 Ø 32 mm, 45°</td> <td>Conduit end piece AJ5.16 Ø 16 mm AJ5.20 Ø 20 mm PMR38 For Ø 16/ 20/ 25 mm</td> <td>Bushing insulators JMKL25.11 Ø 25 mm, sleeve on the plugged end JMKL25.12 Ø 25 mm, sleeve on both ends JMKL32.11 Ø 32 mm, sleeve on the plugged end</td> <td>Curve conduit extension JMKL16 Ø 16 mm JMKL20 Ø 20 mm JMKL25 Ø 25 mm JMKL32 Ø 32 mm JMKL40 Ø 40 mm JMKL50 Ø 50 mm</td> <td>Pre-bent curve conduit extensions 45° sleeve on the long end JMKL20.1 Ø 20 mm JMKL25.1 Ø 25 mm JMKL32.1 Ø 32 mm</td> <td>Pre-bent curve conduit extensions 90° JMKL20.5 Ø 20 mm, 90° JMKL25.2 Ø 25 mm, 90° JMKL32.2 Ø 32 mm, 90° JMKL40.1 Ø 40 mm, 90° JMKL50.1 Ø 50 mm, 90°</td> <td>Pre-bent curve conduit extensions 90° JMKL20.3 Ø 20 mm, 90° JMKL20.4 Ø 20 mm, 90°</td> <td>Pre-bent curve conduit extensions 90° JMKL20.2 Ø 20 mm, 90°</td> </tr> </table>																									Conduit extensions AJ16 Ø 16 mm AJ20 Ø 20 mm AJ25 Ø 25 mm AJ32 Ø 32 mm AJ40 Ø 40 mm AJ50 Ø 50 mm	Bushing flange AS20 For conduit extension Ø 20 mm	Conduit adaptor AJ16.20 Ø 16 mm / 20 mm	The Flexible conduit extension AJP20 Ø 20 mm	Bushing insulators AJ9.16 Ø 16 mm AJ10.20 Ø 20 mm AJ10.25 Ø 25 mm	Bushing insulators AJ13 Ø 32 mm, 90° AJ14 Ø 40 mm, 90° AJ15 Ø 50 mm, 90° AJ15 Ø 32 mm, 45°	Conduit end piece AJ5.16 Ø 16 mm AJ5.20 Ø 20 mm PMR38 For Ø 16/ 20/ 25 mm	Bushing insulators JMKL25.11 Ø 25 mm, sleeve on the plugged end JMKL25.12 Ø 25 mm, sleeve on both ends JMKL32.11 Ø 32 mm, sleeve on the plugged end	Curve conduit extension JMKL16 Ø 16 mm JMKL20 Ø 20 mm JMKL25 Ø 25 mm JMKL32 Ø 32 mm JMKL40 Ø 40 mm JMKL50 Ø 50 mm	Pre-bent curve conduit extensions 45° sleeve on the long end JMKL20.1 Ø 20 mm JMKL25.1 Ø 25 mm JMKL32.1 Ø 32 mm	Pre-bent curve conduit extensions 90° JMKL20.5 Ø 20 mm, 90° JMKL25.2 Ø 25 mm, 90° JMKL32.2 Ø 32 mm, 90° JMKL40.1 Ø 40 mm, 90° JMKL50.1 Ø 50 mm, 90°	Pre-bent curve conduit extensions 90° JMKL20.3 Ø 20 mm, 90° JMKL20.4 Ø 20 mm, 90°	Pre-bent curve conduit extensions 90° JMKL20.2 Ø 20 mm, 90°		
Conduit extensions AJ16 Ø 16 mm AJ20 Ø 20 mm AJ25 Ø 25 mm AJ32 Ø 32 mm AJ40 Ø 40 mm AJ50 Ø 50 mm	Bushing flange AS20 For conduit extension Ø 20 mm	Conduit adaptor AJ16.20 Ø 16 mm / 20 mm	The Flexible conduit extension AJP20 Ø 20 mm	Bushing insulators AJ9.16 Ø 16 mm AJ10.20 Ø 20 mm AJ10.25 Ø 25 mm	Bushing insulators AJ13 Ø 32 mm, 90° AJ14 Ø 40 mm, 90° AJ15 Ø 50 mm, 90° AJ15 Ø 32 mm, 45°	Conduit end piece AJ5.16 Ø 16 mm AJ5.20 Ø 20 mm PMR38 For Ø 16/ 20/ 25 mm	Bushing insulators JMKL25.11 Ø 25 mm, sleeve on the plugged end JMKL25.12 Ø 25 mm, sleeve on both ends JMKL32.11 Ø 32 mm, sleeve on the plugged end	Curve conduit extension JMKL16 Ø 16 mm JMKL20 Ø 20 mm JMKL25 Ø 25 mm JMKL32 Ø 32 mm JMKL40 Ø 40 mm JMKL50 Ø 50 mm	Pre-bent curve conduit extensions 45° sleeve on the long end JMKL20.1 Ø 20 mm JMKL25.1 Ø 25 mm JMKL32.1 Ø 32 mm	Pre-bent curve conduit extensions 90° JMKL20.5 Ø 20 mm, 90° JMKL25.2 Ø 25 mm, 90° JMKL32.2 Ø 32 mm, 90° JMKL40.1 Ø 40 mm, 90° JMKL50.1 Ø 50 mm, 90°	Pre-bent curve conduit extensions 90° JMKL20.3 Ø 20 mm, 90° JMKL20.4 Ø 20 mm, 90°	Pre-bent curve conduit extensions 90° JMKL20.2 Ø 20 mm, 90°																												
<p>Earthing Materials</p>	<table border="0"> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>Strap clamp, terminal AM2 Strap clamp Terminal</td> <td>Earthing strap PP36 Earthing strap 20'</td> <td>Potential equalizer bars AM4 Potential equalizer bar AM5 Potential equalizer bar</td> <td>Protective cover PMR576 Protective cover</td> <td>Earthing terminal AM8 Earthing terminal D8-28</td> <td>Earthing terminal AM9 Earthing terminal D6-15</td> <td>Earthing terminal AM11 Earthing terminal</td> <td>Potential equalizer bar AM6.1 Potential equalizer bar 1/ AM6.3 Potential equalizer bar 1/2'</td> </tr> </table>																Strap clamp, terminal AM2 Strap clamp Terminal	Earthing strap PP36 Earthing strap 20'	Potential equalizer bars AM4 Potential equalizer bar AM5 Potential equalizer bar	Protective cover PMR576 Protective cover	Earthing terminal AM8 Earthing terminal D8-28	Earthing terminal AM9 Earthing terminal D6-15	Earthing terminal AM11 Earthing terminal	Potential equalizer bar AM6.1 Potential equalizer bar 1/ AM6.3 Potential equalizer bar 1/2'	<p>Covers for Mounting Boxes</p> <table border="0"> <tr> <td></td> <td></td> </tr> <tr> <td>Connection cover, IP 44 AK4 Connection cover, IP 44</td> <td>Connection cover, IP 44 AK12.2 Connection cover, IP 44</td> </tr> </table>			Connection cover, IP 44 AK4 Connection cover, IP 44	Connection cover, IP 44 AK12.2 Connection cover, IP 44											
Strap clamp, terminal AM2 Strap clamp Terminal	Earthing strap PP36 Earthing strap 20'	Potential equalizer bars AM4 Potential equalizer bar AM5 Potential equalizer bar	Protective cover PMR576 Protective cover	Earthing terminal AM8 Earthing terminal D8-28	Earthing terminal AM9 Earthing terminal D6-15	Earthing terminal AM11 Earthing terminal	Potential equalizer bar AM6.1 Potential equalizer bar 1/ AM6.3 Potential equalizer bar 1/2'																																	
Connection cover, IP 44 AK4 Connection cover, IP 44	Connection cover, IP 44 AK12.2 Connection cover, IP 44																																							
<p>Mounting Boxes and Accessories</p>	<table border="0"> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>Mounting box AU3.2 Mounting box</td> <td>Mounting box, branched 2-way AU5.2 Mounting box, branched 2-way</td> <td>Low mounting box, branched 2-way AU5.2 Low mounting box, branched 2-way</td> <td>Brick wall mounting box AU3.32 Brick wall mounting box</td> <td>Double mounting box AU17.2 Double mounting box PMR345 Partition plate</td> <td>Mounting box for board walls, 10 to 17 mm board AUS15.12 Mounting box for board walls, 10 to 17 mm board</td> <td>Mounting box for board walls, 22 to 29 mm board AUS15.24 Mounting box for 22-29mm boards</td> <td>Mounting box for board walls AUS15.2 Mounting box for board walls</td> <td>Extension ring PMR94 Extension ring</td> <td>Extension ring PMR410 Extension Ring</td> <td>Extension ring PMR399 Extension ring</td> <td>Extension ring for AU17.2 AK17 Extension ring</td> <td>Interconnectors PMR474 C/C 71 mm PMR490 C/C 85 mm PMR502 C/C 100 mm</td> </tr> </table>																									Mounting box AU3.2 Mounting box	Mounting box, branched 2-way AU5.2 Mounting box, branched 2-way	Low mounting box, branched 2-way AU5.2 Low mounting box, branched 2-way	Brick wall mounting box AU3.32 Brick wall mounting box	Double mounting box AU17.2 Double mounting box PMR345 Partition plate	Mounting box for board walls, 10 to 17 mm board AUS15.12 Mounting box for board walls, 10 to 17 mm board	Mounting box for board walls, 22 to 29 mm board AUS15.24 Mounting box for 22-29mm boards	Mounting box for board walls AUS15.2 Mounting box for board walls	Extension ring PMR94 Extension ring	Extension ring PMR410 Extension Ring	Extension ring PMR399 Extension ring	Extension ring for AU17.2 AK17 Extension ring	Interconnectors PMR474 C/C 71 mm PMR490 C/C 85 mm PMR502 C/C 100 mm		
Mounting box AU3.2 Mounting box	Mounting box, branched 2-way AU5.2 Mounting box, branched 2-way	Low mounting box, branched 2-way AU5.2 Low mounting box, branched 2-way	Brick wall mounting box AU3.32 Brick wall mounting box	Double mounting box AU17.2 Double mounting box PMR345 Partition plate	Mounting box for board walls, 10 to 17 mm board AUS15.12 Mounting box for board walls, 10 to 17 mm board	Mounting box for board walls, 22 to 29 mm board AUS15.24 Mounting box for 22-29mm boards	Mounting box for board walls AUS15.2 Mounting box for board walls	Extension ring PMR94 Extension ring	Extension ring PMR410 Extension Ring	Extension ring PMR399 Extension ring	Extension ring for AU17.2 AK17 Extension ring	Interconnectors PMR474 C/C 71 mm PMR490 C/C 85 mm PMR502 C/C 100 mm																												
<table border="0"> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>Interconnector, board walls AS28 Interconnector</td> <td>Interconnector, board walls AS15 Interconnector, board walls</td> <td>Inlets AN16 Ø 16 mm AN25 Ø 25 mm</td> <td>Angle inlet ANK20 Ø 20 mm</td> <td>Back inlets ANP16 Back inlet D16 ANP20 Back inlet D20 ANP20.1 Angle back inlet D20</td> <td>Strain relief inlet AS12 Strain relief inlet</td> <td>Strain relief AS12.2 Strain relief</td> <td>Reducer AN20.16 Reducer 20 / 16 mm mm</td> <td>Inlets AN9.20 Inlet 20 mm ANK14.20 Angle inlet 20 mm</td> <td>Support PMR577 42 – 90 mm PMR577.65 42 – 65 mm</td> <td>Wall clamp AS8.13 for 12 - 13 mm mm</td> <td>Installation adaptor PMR135 For mounting-/ and junction boxes</td> <td>Screws PLP4.100 3 x 16 mm, 100 pcs PLP5.100 3 x 29 mm, 100 pcs</td> <td>Protective cover PMR1441 Protective cover for the mounting boxes AU3.2 / 5.2 / 6.2 / 3.32</td> </tr> </table>																											Interconnector, board walls AS28 Interconnector	Interconnector, board walls AS15 Interconnector, board walls	Inlets AN16 Ø 16 mm AN25 Ø 25 mm	Angle inlet ANK20 Ø 20 mm	Back inlets ANP16 Back inlet D16 ANP20 Back inlet D20 ANP20.1 Angle back inlet D20	Strain relief inlet AS12 Strain relief inlet	Strain relief AS12.2 Strain relief	Reducer AN20.16 Reducer 20 / 16 mm mm	Inlets AN9.20 Inlet 20 mm ANK14.20 Angle inlet 20 mm	Support PMR577 42 – 90 mm PMR577.65 42 – 65 mm	Wall clamp AS8.13 for 12 - 13 mm mm	Installation adaptor PMR135 For mounting-/ and junction boxes	Screws PLP4.100 3 x 16 mm, 100 pcs PLP5.100 3 x 29 mm, 100 pcs	Protective cover PMR1441 Protective cover for the mounting boxes AU3.2 / 5.2 / 6.2 / 3.32
Interconnector, board walls AS28 Interconnector	Interconnector, board walls AS15 Interconnector, board walls	Inlets AN16 Ø 16 mm AN25 Ø 25 mm	Angle inlet ANK20 Ø 20 mm	Back inlets ANP16 Back inlet D16 ANP20 Back inlet D20 ANP20.1 Angle back inlet D20	Strain relief inlet AS12 Strain relief inlet	Strain relief AS12.2 Strain relief	Reducer AN20.16 Reducer 20 / 16 mm mm	Inlets AN9.20 Inlet 20 mm ANK14.20 Angle inlet 20 mm	Support PMR577 42 – 90 mm PMR577.65 42 – 65 mm	Wall clamp AS8.13 for 12 - 13 mm mm	Installation adaptor PMR135 For mounting-/ and junction boxes	Screws PLP4.100 3 x 16 mm, 100 pcs PLP5.100 3 x 29 mm, 100 pcs	Protective cover PMR1441 Protective cover for the mounting boxes AU3.2 / 5.2 / 6.2 / 3.32																											